

All Dimensions with 1/8" Growth Factor Figured In Per Unit

Space Requirement Chart

Club Model (24" Width)

<u>No. of Columns</u>	<u>Run In Feet</u>	<u>Run In Inches</u>	<u>No. of Units</u>
1	2'-0 11/16"	24 11/16	1-1 column
2	4'-0 5/16"	48 5/16	1-2 column
3	6'-1"	73	1-2,1-1 column
4	8'-0 5/8 "	96 5/8	2-2 column
5	10'-1 5/16"	121 5/16	2-2,1-1 column
6	12'-0 15/16"	144 15/16	3-2 column
7	14'-1 5/8 "	169 5/8	3-2,1-1 column
8	16'-1 1/4 "	193 1/4	4-2 column
9	18'-1 15/16"	217 15/16	4-2,1-1 column
10	20'-1 9/16"	241 9/16	5-2 column
11	22'-2 1/4 "	266 1/4	5-2,1-1 column
12	24'-1 7/8 "	289 7/8	6-2 column
13	26'-2 9/16"	314 9/16	6-2,1-1 column
14	28'-2 3/16"	338 3/16	7-2 column
15	30'-2 7/8 "	362 7/8	7-2,1-1 column
16	32'-2 1/2 "	386 1/2	8-2 column
17	34'-3 3/16"	411 3/16	8-2,1-1 column
18	36'-2 13/16"	434 13/16	9-2 column
19	38'-3 1/2 "	459 1/2	9-2,1-1 column
20	40'-3 1/8 "	483 1/8	10-2 column
21	42'-3 13/16"	507 13/16	10-2,1-1 column
22	44'-3 7/16"	531 7/16	11-2 column
23	46'-4 1/8 "	556 1/8	11-2,1-1 column
24	48'-3 3/4 "	579 3/4	12-2 column
25	50'-4 7/16"	604 7/16	12-2,1-1 column
26	52'-4 1/16"	628 1/16	13-2 column
27	54'-4 3/4 "	652 3/4	13-2,1-1 column
28	56'-4 3/8 "	676 3/8	14-2 column
29	58'-5 1/16"	701 1/16	14-2,1-1 column
30	60'-4 11/16"	724 11/16	15-2 column
31	62'-5 3/8 "	749 3/8	15-2,1-1 column
32	64'-5"	773	16-2 column
33	66'-5 11/16"	797 11/16	16-2,1-1 column
34	68'-5 5/16"	821 5/16	17-2 column
35	70'-6"	846	17-2,1-1 column
36	72'-5 5/8 "	869 5/8	18-2 column
37	74'-6 5/16"	894 5/16	18-2,1-1 column
38	76'-5 15/16"	917 15/16	19-2 column
39	78'-6 5/8 "	942 5/8	19-2,1-1 column
40	80'-6 1/4 "	966 1/4	20-2 column
41	82'-6 15/16"	990 15/16	20-2,1-1 column
42	84'-6 9/16"	1014 9/16	21-2 column
43	86'-7 1/4 "	1039 1/4	21-2,1-1 column
44	88'-6 7/8 "	1062 7/8	22-2 column
45	90'-7 9/16"	1087 9/16	22-2,1-1 column
46	92'-7 3/16"	1111 3/16	23-2 column
47	94'-7 7/8 "	1135 7/8	23-2,1-1 column
48	96'-7 1/2 "	1159 1/2	24-2 column
49	98'-8 3/16"	1184 3/16	24-2,1-1 column
50	100'-7 13/16"	1207 13/16	25-2 column